


A portable, open source platform for analog and digital input specially designed for use with digital audio workstations and other music software. Powered by a Teensy microcontroller.

Default hardware and software setup



Blue font is Teensy pin number

Magenta font is preprogrammed MIDI mapping (cc: continuous controller number, n: note number)

features:

- preprogrammed as a class compliant MIDI device (no special driver needed)
- 6 continuous controller inputs for analog or digital communication
- preprogrammed contact microphone envelope following (initiate the dip switches)

input uses (tip: pin, ring: +3.3v, sleeve: GND):

digital input (foot pedals, buttons, switches, etc.)

analog input (expression pedals, knobs, expression pedals, contact microphones)